

# Cryotech Kilfrost ABC-S Plus Refractive Index/BRIX vs Temperature

Field Use/Receiving Inspection Only

Measurement of sample temperature required prior to using this chart

Whenever possible, bring sample temperature to 20 deg C before analyzing

